

SINK DRAIN INSTALLATION GUIDE

Model

S2007

S2008

S2017 S2018

Series

CUSTOMER SERVICES



cs@keshome.com




GEN-S2008-EN-V2.1

Note: The following steps use Model #: S2008A (with overflow) as an example for illustration.

WITH overflow: S2007A/S2008A/S2017A/S2018A

WITHOUT overflow: S2007D/S2008D/S2017D/S2018D

ILLUSTRATED PARTS Pop-Up Stopper



⊣ Tailpiece Nut

product for accuracy.

AFTER-SALE SERVICE



24- Hour Customer Support

Visit our customer support center at www.keshome.com/help, available 24/7. Contact us via Amazon Message, instant chat, and email during business hours.



Free Replacement Parts

Please contact us if any parts are damaged or missing. Parts provided free.

(Shipping fees may apply)



1-on-1 Responsive Customer Service

No need to restate your case with each contact.

Our dedicated team of professionals will work on resolving your issue until it is resolved.



Parts Customization

No need to worry about unexpected challenges.
Share your requirements, and we'll customize parts to meet your specific needs.



Return Policy

Feel free to return within 30 days. Please ensure all items (particularly the hardware pack) are in the box before returning.

Missing Return Window?


No Worry! We totally understand





Contact us Replace for FREE


INSTALLATION


Model #: S2008A is used as an example for illustration.














LEAKAGE SOLUTION



Wrap the plumber's putty around the flange bottom and reinstall.






Still leaking? Contact KES! cs@keshome.com



FOR 1-1/2" TRAP

Please use the free 1-1/2" gasket to replace the old one in your trap. $\,$



TROUBLESHOOTING

If the drain does not work properly, please take the following corrective actions:

1. PROBLEM

The pop-up stopper sticks and is hard to push down.

CAUSE

The pop-up bolt is jammed.

ACTION

Contact us to replace the pop-up bolt.

2. PROBLEM

The pop-up flange (or strainer basket) and the pop-up stopper aren't straight.

CAUSE

The package may have been damaged during transit.

ACTION

Try straightening the part or contact us for a how-to video guide.

3. PROBLEM

The drain is leaking underneath the sink.

CAUSE

The gasket B doesn't seal strong enough.

ACTION

Adjust the gasket or seal around it with the silicone caulk.

4. PROBLEM

There's a leak between the gasket D, C and the locknut.

CAUSE

The gasket C may be upside down or the locknut doesn't seal strong enough.

ACTION

Remove the locknut and the gasket C, then use plumbers tape or silicone caulk on the thread. Check that the gasket is right side up before putting it back on the gasket C along with the locknut.

5. PROBLEM

Size is not compatible.

CAUSE

Designed for a standard 13/4" drain opening. Fits sink holes with a diameter of 15/8" to 131/32" and sinks up to 131/32" thick.

ACTION

Double check the size before installing it. If it's not compatible, just put all items in the box and return the product to Amazon.

6. PROBLEM

Drains slowly or water is unable to drain.

CAUSE

Debris is blocking the drain.

ACTION

Take out the basket (if there is one) to check and clean the drain.

Care Instructions

Use soft, damp cloth. Dry thoroughly. Avoid harsh cleaners for effective maintenance.

One-Year Limited Warranty

KES warrants its products purchased from authorized sellers to be free from defects in material and workmanship for one (1) year from the original date of purchase.

What We Will Do

KES will repair or replace, FREE OF CHARGE, during the one (1) year warranty period, any part that proves defective in material and/or workmanship under normal installation, use and service. If repair or replacement is not practical, KES may elect to refund the purchase price in exchange for the return of the product.

What Is Not Covered

KES shall not be liable for any damage to the product resulting from reasonable wear and tear, installation and maintenance errors, outdoor use, freezing water, abuse, misuse, and use of cleaners containing abrasive cleansers, ammonia, bleach, acids, waxes, alcohol or other organic solvents.

KES is not responsible for removal, installation, labor charges, or other incidental or consequential costs. In no event shall the liability of KES exceed the purchase price of the product.

KES AND/OR SELLER ARE PROVIDING THESE WARRANTIES IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABLITY AND HITSES FOR A PARTICULAR PURPOSE. KES AND/OR SELLER DISCLAIM ALL LIABILITY FOR SPECIAL, INCIDENTAL OR CONSEQUENTAL DAMAGES.

Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so these limitations and exclusions may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from jurisdiction to jurisdiction.

This warranty applies only to KES products sold in North America and Europe.

Supplementary Terms

Warranty terms may vary depending on the laws and regulations of the country or region where the product is sold. Consumers may have statutory warranty rights under local consumer protection laws that are not affected by the terms of this commercial warranty. For specific warranty rights applicable in your region, please refer to local consumer protection leaislation.

Contact KES

Email: cs@keshome.com



Please provide:

- dated proof of purchase
- · decription of the defect/fault
- picture or video showing the issue(s) (optional)

